

## Vending Machine

# D.A. CRISTALLO 400



Type: D.A. FS 400



## MAIN PARTS




Fig. 1

- |   |  |
|---|--|
| <b>1</b> Door lock  | <b>19</b> Spiral mixer                 |
| <b>2</b> Display  | <b>20</b> Brew group                   |
| <b>3</b> Product keypad                                   | <b>21</b> Drip Tray                    |
| <b>4</b> Coin slot  | <b>22</b> Dispensing arm               |
| <b>5</b> Change return key                                | <b>23</b> Coffee ground channel        |
| <b>6</b> Instruction plate                                | <b>24</b> Fluid discharge tank         |
| <b>7</b> Dispensing outlet door (beverage/cup dispensing) | <b>25</b> Collecting tray              |
| <b>8</b> Change removal outlet                            | <b>26</b> Door open alarm switch       |
| <b>9</b> Power cord socket                                | <b>27</b> CPU card                     |
| <b>10</b> Water connection coupling                       | <b>28</b> Cup dispenser                |
| <b>11</b> Safety switch                                   | <b>29</b> Stirrer dispenser            |
| <b>12</b> Air break device                                | <b>30</b> Sugar container              |
| <b>13</b> Container 1/2 (instant products)                | <b>31</b> Change-giving coiner support |
| <b>14</b> Container 3/4 (instant products)                | <b>32</b> Dispensing outlet            |
| <b>15</b> Coffee bean hopper                              | <b>33</b> Coin return duct             |
| <b>16</b> Coffee grinder                                  | <b>34</b> Coin box set                 |
| <b>17</b> Mixer   | <b>35</b> Sugar opening                |
| <b>18</b> Instants opening                                | <b>36</b> Chute                        |

