







**All Parts for All Sections**

Part #	Part Name	Type	Sub
56001440	AIR GUIDE		
56001459	BLOWER MOTOR ASSY	F	54127058
56001436	DIODE	F	
56001475	FUSE, 12 A	F	M0805105
56001474	FUSE, HV	F	
56001426	FUSE, THERMAL- CAVITY	F	
56001478	HARNESS MAIN	F	
12002625	KIT, COVER/STIRRER BLADE/RIVETS	F	
12002624	KIT, SPRING/LATCH/CHOKE COVERF		
56001463	LAMP/ SOCKET ASSY		56002007
56001462	MAGNETRON	F	59004010
56001460	MOTOR, ANTENNA	F	54126033
56001428	NLA- AIR DEFLECTOR- REAR	F	
56001472	NLA- BOARD, HV/LV	F	
56001218	NLA- BRACKET, CAPACITOR	F	
56001464	NLA- CAPACITOR	F	
56001481	NLA- DOOR ASSY- MENUMASTER	F	
56001482	NLA- FOOT COVER	None	
56001224	NLA- FOOT, BASE	F	
56001468	NLA- FUSE BLOCK / FILTER ASSY	F	
56001439	NLA- HINGE, BOTTOM	F	
56001480	NLA- RELAY ASSY	F	
56001210	NLA- SCREW	F	
56001217	NLA- SCREW	F	
56001222	NLA- SCREW	F	
56001230	NLA- SCREW	F	
56001461	NLA- SCREW	F	
56001470	NLA- SCREW		
56001447	NLA- SUPPORT	F	
56001471	NLA- TOUCH PANEL ASSY	F	
56001465	NLA- TRANSFORMER, HV	F	
56001429	NLA- WRAPPER	F	
56001051	NUT, HINGE	F	20003101
56001476	POWER CORD (EU)	F	20243501
56001450	RIVET ASSY		
56001151	SCREW	None	20280101
56001153	SCREW	None	20275405
56002011	SWITCH, INTERLOCK ASSY	F	56002052
56001432	THERMAL CUTOFF, MAG	F	54116023
56001441	TRAY ASSY	F	54127018